

# Recent Advances in Flexible Foam

Mark McBride & Willie Wesley III

PFA: November 4, 2021, Charlotte, NC

# Agenda

## TOPIC 1: Improved Green Strength in Slab and Molded Applications (Mark McBride)

- Overview
- Experimental Design
- Results
- Conclusion & Takeaways

## TOPIC 2: Next Generation Gel Formulations for Flexible Slab Foams (Willie Wesley III)

- Overview
- Experimental Design
- Results
- Conclusions & Takeaways



## Q&A

# Overview: Improved Green Strength in Slab and Molded Applications

## Current Challenges

- HyperSoft™ foam formulations exhibit slow cure times and poor green strength on production slab lines
- Foam buns adhere to conveyer lines and rollers
- Softer formulations in molded applications exhibit similar processing drawbacks

## Solution

- Develop new high ethylene oxide polyether polyol (Pluracol® 2029/1) to use in place of Pluracol® 593
- Compare foam formulations made with Pluracol® 2029/1 to those made with Pluracol® 593 polyol

**Table 1 – Pluracol® 2029/1 Polyol Properties**

Pluracol® 2029/1 Properties	
Hydroxyl number, mg KOH/g	44.0 - 47.0
Molecular Weight	4,360
Viscosity @77F, cps	985

# Experimental Design: Improved Green Strength in Slab and Molded Applications

## Experiments

- Experiment #1 – Gel Viscosity Testing
- Experiment #2 – Cannon Viking Slab Foam Machine Testing
- Experiment #3 – Molded Pillows Testing

## Experiment #1 – Gel Viscosity Testing

- Measure viscosity throughout TDI-based urethane reaction
- Brookfield DV-III Ultra Programmable Rheometer (LV-3 spindle) - collect data every 10 sec during reaction

**Figure 1** – Benchtop Rheometer Set-Up



**Table 2** – Formulations for Gel Viscosity Testing

Formulation (pbw)	1	2
Pluracol® 593 polyol	100	
Pluracol® 2029/1 polyol		100
Stannous Octoate	0.2	0.2
Lupranate® T-80 TDI	7.1	7.1
TDI Index	100	100

# Experimental Design: Improved Green Strength in Slab and Molded Applications

## Experiment #2 – Cannon Viking Slab Foam Machine Testing

- Compare HyperSoft™ foam formulations: Pluracol® 2029/1 vs. Pluracol® 593 polyol on pilot slab machine
- 42” height by 50” width foam buns made in accordance with ASTM D3574

**Table 3 – Low Density HyperSoft™ Foam Formulations**

Formulation (pbw)	1	2	3	4	5	6
Pluracol® 593 polyol				78	78	78
Pluracol® 2100 polyol	22	22	22	22	22	22
Pluracol® 2029/1 polyol	78	78	78			
Water	4.5	4.5	4.5	4.5	4.5	4.5
Momentive NIAX™ Silicone L635	1.4	1.4	1.4	1.4	1.4	1.4
Evonik DABCO® NE500	0.09	0.09	0.09	0.09	0.09	0.09
Evonik DABCO® NE300	0.03	0.03	0.03	0.03	0.03	0.03
Evonik DABCO® T-9	0.16	0.12	0.08	0.16	0.12	0.08
Methyl Formate	3	3	3	3	3	3
Lupranate® T-80 TDI	50.8	50.8	50.8	50.9	50.9	50.9
TDI Index	102	102	102	102	102	102

**Table 4 – Higher Density HyperSoft™ Foam Formulations**

Formulation (pbw)	1	2	3	4	5	6
Pluracol® 593 polyol				78	78	78
Pluracol® 2100 polyol	22	22	22	22	22	22
Pluracol® 2029/1 polyol	78	78	78			
Water	3.2	3.2	3.2	3.2	3.2	3.2
Momentive NIAX™ Silicone L635	1.4	1.4	1.4	1.4	1.4	1.4
Evonik DABCO® NE500	0.12	0.12	0.12	0.12	0.12	0.12
Evonik DABCO® NE300	0.04	0.04	0.04	0.04	0.04	0.04
Evonik DABCO® T-9	0.16	0.12	0.08	0.16	0.12	0.08
Lupranate® T-80 TDI	37.7	37.7	37.7	37.8	37.8	37.8
TDI Index	101	101	101	101	101	101

# Experimental Design: Improved Green Strength in Slab and Molded Applications

## Experiment #3 – Molded Pillows Testing

- Compare hybrid-viscoelastic formulations: Pluracol® 2029/1 vs. Pluracol® 593 polyol in molded pillows
- Pillow mold heated to 125°F and all formulations demolded after 10 minutes

**Table 5** – Hybrid Foam Molded Pillows

Formulation (pbw)	Formulation 1		Formulation 2	
Pluracol® 593 polyol	82.0		82.0	
Pluracol® 2029/1 polyol		82.0		82.0
Pluracol® 4156 polyol	18.0	18.0		
Pluracol® 1538 polyol			18.0	18.0
Evonik DABCO® DC198	1.5	1.5	1.5	1.5
Evonik DABCO® NE300	0.25	0.25	0.25	0.25
Evonik DABCO® NE500	0.25	0.25	0.25	0.25
Water	3.0	3.0	3.0	3.0
Lupranate® L5100 MDI	43.9	43.9	43.9	43.9
MDI Index	80	80	80	80

**Figure 2** – Pillow Mold Set-Up




# Results: Improved Green Strength in Slab and Molded Applications

## Experiment #1 – Gel Viscosity Testing

- Pluracol® 2029/1 polyol demonstrated a 20% faster cure time compared to Pluracol® 593 polyol in identical TDI formulations

**Figure 3** – Gel Viscosity Test: Pluracol® 593 vs. Pluracol® 2029/1 polyol



## Results: Improved Green Strength in Slab and Molded Applications

### Experiment #2 – Cannon Viking Slab Foam Machine

- HyperSoft™ foam formulations with Pluracol® 593 polyol are not fully cured coming off pilot scale slab line, causing foam buns to stick to rollers leading to difficulty handling
- HyperSoft™ foam formulations with Pluracol® 2029/1 polyol displayed reduced tackiness and faster cure times, allowing for easier handling of foam buns
- No negative impact on physical properties were observed

**Figure 4** – Handling of Foam Buns on Pilot Scale Slab Machine





# Results: Improved Green Strength in Slab and Molded Applications

## Experiment #3 – Molded Pillows

- Slightly higher density and IFD when Pluracol® 2029/1 polyol was used in formulations
- De-mold times held constant; however, pillows made with P2029/1 were less tacky coming out of mold

**Table 6** – Molded Pillow Formulation Physical Properties

Physical Properties	Formulation 1		Formulation 2	
	P593	P2029/1	P593	P2029/1
Air Flow (cfm)	>8	>8	>8	>8
CFD Humid Aged (50 % Retained)	64	64	64	66
Compression Set (Ct) 50 %	4	5	4	4
Compression Set (Ct) 90 %	3	5	4	6
Compression Set Humid Aged (Ct) 50 %	7	7	5	5
Compression Set Humid Aged (Ct) 90 %	7	7	4	5
Core Density (pcf)	2.63	2.73	2.71	2.79
Original IFD at 25 %	5.8	7.5	7.0	9.2
Original IFD at 65 %	15.6	20.0	17.3	22.5
Original IFD at 25 % Return	5.3	6.8	6.6	8.3
% Recovery	92	91	94	90
Support Factor	2.69	2.67	2.48	2.46
Recovery Time (sec)	1	1	1	1
D3574 Resilience (%)	27	30	25	25
Tensile Strength (psi)	8	9	7	7
Ultimate Elongation (%)	173	149	153	130
Tg (°C)	0	-5	-1	-1

# Results: Improved Green Strength in Slab and Molded Applications

## Additional Experiments – TDI Viscoelastic Foams

- Formulations using 59 pbw of Pluracol® 2029/1 in comparison to Pluracol® 593 polyol
  - No change in hardness and density
  - Higher airflow
    - Formulation 1: 66% increase
    - Formulation 2: 39% increase
  - Better damping
    - Higher hysteresis (+4%)
    - Lower ball rebound (6% vs. 9%)



## Conclusions: Improved Green Strength in Slab and Molded Applications

- Pluracol<sup>®</sup> 2029/1 polyol demonstrates *faster cure times* and *improved green strength* compared to Pluracol<sup>®</sup> 593 polyol as a drop-in for flexible foam formulations
  - These improvements can aid in slab and molded production processes by:
    - Ease of bun handling
    - Faster processing times
  - No negative impacts on mechanical properties of the finished polyurethane foams were observed
- Contact Mark McBride (mark.mcbride@basf.com) for Pluracol<sup>®</sup> 2029/1 polyol inquiries

**Table 1** – Pluracol<sup>®</sup> 2029/1 Polyol Properties

Pluracol <sup>®</sup> 2029/1 Properties	
Hydroxyl number, mg KOH/g	44.0 - 47.0
Molecular Weight	4,360
Viscosity @77F, cps	985

# Overview: Next Generation Gel Formulations for Flexible Slab Foams

## Current Challenges

- Solid formation with original Elastopan<sup>®</sup> polyurethane gels caused clogging in CO<sub>2</sub> process filters
- Next gen offerings must provide same benefits:
  - Cooling effects
  - Ease of use
  - Neutralization of tin (HR gel)
- Improve sustainability / environmental position of get components



## Solution

- Improve processing ease of Elastopan<sup>®</sup> polyurethane gels while maintaining performance
  - Gel catalyst was hypothesized to be the driver of solids formation
    - Test Elastopan<sup>®</sup> 5291TW gel using CO<sub>2</sub> process to verify gel is no longer clogging filters
    - Pour HR foams via trough pour process to demonstrate HR-2 gel performance

# Experimental Design: Next Generation Gel Formulations for Flexible Slab Foams

## Experiments

- Experiment #1 – Catalyst Selection Testing
- Experiment #2 – Gel Viscosity Testing
- Experiment #3 – Cannon Viking CO<sub>2</sub> Process Slab Foam Machine Testing
- Experiment #4 – Cannon Viking HR Slab Foam Machine Testing

## Experiment #1 – Catalyst Selection Testing

- Synthesize gel prototypes varying only the catalyst between formulations
- Confirm gel reactions profiles via smooth flow and no solids generation

**Table 7** – Basic Polyurethane Gel components

<b>Polyol</b>
<b>Plasticizer</b>
<b>Isocyanate</b>
<b>Catalyst</b>
<b>Colorant (optional)</b>

## Results: Next Generation Gel Formulations for Flexible Slab Foams

### Experiment #1 – Catalyst Selection Testing

- Catalysts were evaluated by the following criteria:
  - Potency
  - Environmental impact
  - Supply availability
- Catalyst type was varied, but remaining parameters were held constant:
  - Catalyst concentration
  - Addition process
  - Resonance time

### Experiment #2 – Gel Viscosity Testing

- Gel viscosities curves were generated to confirm desired processing range (<5000 cPs)


### Experiment #3 – Cannon Viking HR Slab Foam Machine Testing

- HR slab foams were produced via trough pour process on Cannon Viking Slab Pilot Machine

### Experiment #4 – Cannon Viking CO<sub>2</sub> Process Slab Foam Machine Testing

- Experimental gel was foamed in a conventional formula via NOVAFLEX® dispensing process
- Formulations with and without gel were run side-by-side to measure potential pressure increase
  - Loading levels were varied to ensure safe pressures at multiple outputs

Figure 5 – NOVAFLEX® dispensing process




# Results: Next Generation Gel Formulations for Flexible Slab Foams

## Experiment #2 – Gel Viscosity Testing

- Elastopan® 5291 TW gel showed a slight decrease in viscosity compared to original formulation
- Elastopan® HR-2 gel met acceptable viscosity range for urethane gel used in slab processes

**Figure 6 – Gel Viscosity Curves for Elastopan® Polyurethane Gel Prototypes**



# Results: Next Generation Gel Formulations for Flexible Slab Foams

## Experiment #3 – Cannon Viking HR Slab Foam Machine Testing

- Elastopan® HR gel performs two primary functions: neutralizes T-12 (dibutyltin dilaurate) and provides cooling effect
- HR foam was poured via trough method using the new HR-2 formula to verify tin neutralization continued
  - Proper tin neutralization was confirmed by a significant reduction in compression set loss

**Table 8:** HR-2 Gel Trough Pour Trial Compression Set Properties

<u>Physical Properties</u>	1	2	3	4	5	6
<b>Compression Sets (% set)</b>						
50%	10.0	7.8	5.3	6.1	4.6	6.5
90%	39.5	8.8	8.1	6.7	5.9	5.5
50%**	14.9	8.4	7.5	8.1	7.0	7.0
90%**	69.1	18.3	15.8	36.4	14.2	11.2
<b>CFD (% Of Original 50%)</b>	0.4	0.4	0.5	0.5	0.6	0.6
<b>Air Flow (cfm)</b>	0.9	0.9	1.1	0.8	0.8	0.7

**NOTE:** Samples 1 and 4 have 0 pts, Samples 2 and 5 have 4 pts and Samples 3 and 6 have 8 pts of HR gel.

\*\*Humid Aged – 220°F for 3hrs



## Results: Next Generation Gel Formulations for Flexible Slab Foams

### Experiment #4 – Cannon Viking CO<sub>2</sub> Process Slab Foam Machine Testing


- Original Elastopan<sup>®</sup> 5291T gel led to consistent shutdowns due to pressure increases from clogged filters
- Elastopan<sup>®</sup> 5291TW gel ran successfully with same foam formulations generating +21 – 29 psig pressure

**Table 9 - NOVAFLEX<sup>®</sup> Manifold Pressures**

Process Data	1	2	3	4	5	6
Manifold Pressure (psig)	153	154	154	182	180	175
Throughput (kg/min)	30.0	30.0	30.0	30.0	30.0	30.0
Conveyor Speed (ft/min)	11.0	11.0	11.0	11.0	11.0	11.0

## Conclusions: Next Generation Gel Formulations for Flexible Slab Foams

- BASF has developed the next generation of Elastopan<sup>®</sup> polyurethane gels via a catalyst change:
    - No CO<sub>2</sub> filter clogging while still maintaining desired physical properties as a drop-in
    - Tin neutralization in HR foam formulations to prevent urethane “unzipping”
    - Improved sustainability profile of gels
- Contact Willie Wesley III ([willie.wesley@basf.com](mailto:willie.wesley@basf.com)) for Elastopan<sup>®</sup> gel product inquiries



**Figure 7** – Elastopan<sup>®</sup> gel incorporated via swirl pattern (left). Elastopan<sup>®</sup> gel incorporated in ribbon pattern (middle). Elastopan<sup>®</sup> gel fully mixed into the foam (right).

# Q & A

# Fair Use Notice

This presentation may contain copyrighted material, the use of which may not have been specifically authorized by the copyright holder. To the extent this presentation contains any such copyrighted material, the material is being used for nonprofit educational purposes reflecting a permitted “fair use” thereof as authorized under Title 17 U.S.C. Section 107. If any copyrighted material included from this presentation is further used for purposes that go beyond “fair use,” the copyright holder’s permission is required.



We create chemistry

# Back-Up Slides

**Table 10** – Low Density HyperSoft™ Foam Formulations Physical Properties

Physical Properties	Pluracol® 2029/1			Pluracol® 593		
	1	2	3	4	5	6
Density (pcf)	0.99	1.01	1.02	1.06	1.09	1.08
Tensile (psi)	10	13	14	8	10	11.
Elongation (%)	289	332	347	338	310	419
Heat Aged Tensile (psi)	10	11	12	7	9	10
Heat Aged Elongation (%)	296	311	340	304	297	384
Tear (pi)	2.7	3.1	3.2	2.7	2.5	2.7
Resilience (%)	43	43	44	40	44	47
IFD, lb. /50 sq. in. (4 in.)						
25%	9.3	10.0	10.0	9.9	9.9	9.2
65%	19.9	21.7	22.0	21.2	21.3	20.4
25% Return	6.0	6.7	6.8	6.7	6.8	6.6
Support Factor	2.15	2.17	2.20	2.13	2.16	2.20
Recovery (%)	65	67	68	68	69	71
Compression Sets, % set						
50%	10	8	13	8	8	7
90%	16	22	39	8	10	12
50%**	26	26	25	25	24	25
90%**	43	40	41	41	57	44
CFD (% of Original 50%)	54	48	47	44	45	41
Air Flow (cfm)	>8	>8	>8	>8	>8	>8
Fatigue Properties						
Static Fatigue						
Height (% Loss)	3.8	4.0	4.7	2.7	3.4	4.4
IFD: 25% Loss	39	37	35	35	36	37
IFD: 65% Loss	34	32	30	31	31	32
Pounding, 80k cycles						
Height (% Loss)	4.0	4.0	4.5	2.7	3.5	3.8
40% IFD (% Loss)	44	42	39	41	40	38

**Table 11** – Higher Density HyperSoft™ Foam Formulations Physical Properties

Physical Properties	Pluracol® 2029/1			Pluracol® 593		
	1	2	3	4	5	6
Density (pcf)	1.62	1.67	1.70	1.77	1.77	1.82
Tensile (psi)	20	21	20	21	23	23
Elongation (%)	383	382	382	483	439	419
HTAG Tensile (psi)	18	20	19	18	21	21
HTAG Elongation (%)	364	391	385	470	442	407
Tear (pi)	3.8	4.2	4.1	4.3	4.2	4.2
Resilience (%)	31	38	41	33	30	40
IFD, lb. /50 sq. in. (4 in.)						
25%	14.9	14.6	14.6	14.0	14.9	14.6
65%	33.9	33.0	32.0	32.1	34.3	33.1
25% Return	10.8	10.8	11.1	10.4	11.4	11.5
Support Factor	2.28	2.27	2.20	2.30	2.30	2.27
Recovery (%)	73	74	76	74	77	79
Compression Sets (%set)						
50%	11	6	4	9	5	4
90%	69	55	24	62	58	43
50%**	23	27	28	26	28	34
90%**	66	66	70	63	57	73
CFD (% Of Original 50%)	37	37	33	33	33	31
Air Flow (cfm)	1.8	2.2	2.6	1.3	1.0	1.8
Fatigue Properties						
Static Fatigue						
Height (% Loss)	5.2	2.9	3.0	3.5	2.9	4.3
IFD (25% Loss)	32	26	28	32	28	28
IFD (65% Loss)	28	23	26	29	26	25
Pounding (80k cycles)						
Height (% Loss)	3.4	3.2	1.9	2.8	2.8	3.1
40% IFD (% Loss)	34	36	30	35	30	31

Recent Advances in Flexible Foams

**Table 12 - Elastopan® 5291TW Polyurethane Gel  
NOVAFLEX® CO<sub>2</sub> Trial Physical Properties**

Physical Properties	1	2	3	4	5	6
Density (pcf)	1.17	1.19	1.25	1.27	1.24	1.25
Tensile (psi)	14.5	12.3	14.8	15.5	13.8	12.6
Elongation (%)	142	129	154	174	138	143
Heat Aged Tensile (psi)	14.4	14.6	14.6	16.1	15.6	13.8
Heat Aged Elongation (%)	178	194	182	212	194	176
Tear (pi)	2.3	2.1	2.0	2.2	2.2	2.2
Resilience (%)	41	45	47	46	45	46
IFD, lb. /50 sq. in. (4 in.)						
25%	30.2	28.6	26.6	29.8	29.1	25.5
65%	61.3	57.8	55.1	60.4	58.5	51.2
25% Return	20.6	20.0	19.3	21.2	20.6	18.2
Support Factor	2.03	2.02	2.07	2.02	2.01	2.01
Recovery (%)	68	70	73	71	71	72
Compression Sets (% set)						
50%	0.6	1.3	0.7	1.9	1.1	0.9
90%	5.3	3.3	2.7	11.8	3.7	3.2
50%**	3.7	2.6	1.4	3.5	2.4	1.7
90%**	26.4	27.5	16.5	35.8	16.7	13.4
CFD, % Of Original 50%	0.44	0.41	0.37	0.38	0.42	0.38
Air Flow (cfm)	1.7	4.2	5.2	2.6	3.7	5.4
Fatigue Properties						
Static Fatigue						
Height (% Loss)	3	1	1	2	2	1
IFD (25% Loss)	29	20	19	19	20	23
IFD (65% Loss)	24	17	17	16	18	22

**Table 13 – HR-2 Gel Trough Pour Trial Physical Properties**

Physical Properties	1	2	3	4	5	6
Density (pcf)	1.67	1.80	1.92	2.23	2.51	2.83
Tensile (psi)	19.5	21.5	20.4	22.5	22.7	23.7
Elongation (%)	183	177	171	170	146	138
Heat Aged Tensile (psi)	16.2	19.9	19.1	8.0	22.7	23.5
Heat Aged Elongation (%)	196	178	177	119	179	163
Tear (pi)	2.3	2.3	2.1	1.9	1.8	1.7
Resilience (%)	52	59	60	59	64	63
IFD, lb. /50 sq. in. (4 in.)						
25%	19	21	23	24	27	30
65%	45	51	56	59	71	84
25% Return	15	17	18	20	24	26
Support Factor	2.37	2.44	2.46	2.48	2.58	2.82
Recovery (%)	77	80	80	84	86	87
Compression Sets (% set)						
50%	10.0	7.8	5.3	6.1	4.6	6.5
90%	39.5	8.8	8.1	6.7	5.9	5.5
50%**	14.9	8.4	7.5	8.1	7.0	7.0
90%**	69.1	18.3	15.8	36.4	14.2	11.2
CFD (% Of Original 50%)	0.4	0.4	0.5	0.5	0.6	0.6
Air Flow (cfm)	0.9	0.9	1.1	0.8	0.8	0.7
Fatigue Properties						
Static Fatigue						
Height (% Loss)	6	7	4	4	4	4
IFD (25% Loss)	31	33	23	22	20	19
IFD (65% Loss)	26	28	18	19	20	22
Pounding, 80k cycles						
Height (% Loss)	3.9	3.6	3.4	2.8	2.2	1.6
40% IFD (% Loss)	30	31	17	18	18	19